

Remote Control Code Reference DVD · Satellite · Television · CBL



Porter Lancaster Limited · Lower Healey Business Park · Froom Street · Chorley · Lancashire · UK · PR6 9AR

Tel: 0870 871 0111 · Fax: 0870 871 0112 · eMail: sales@porta.co.uk · Web: www.tilevision.tv

Receiver Brand	Setup Code
----------------	------------

AB Sat	161
ABsat	189,190,199
AGS	189
Akai	093,122
Alba	051,052,053,054,081,095,131,144,190
Aldes	053,054,055,126,131
Allsat	056,075,093,112,121,122
Allsonic	054,060,126,182
Alltech	147,190
Alpha	122
Altai	133
Amitronica	190
Ampere	058,133,177
Amstrad	057,094,010,125,129,133,149,151,155,162,177,183,190,194,195
Anglo	190
Ankaro	054,060,123,126,182,190
Anttron	051,054,121,144
Apollo	051
Arcon	058,059,076,153,177
Armstrong	057,122
ASA	134
Asat	093,122
ASLF	190
AST	064,127
Astacom	154,189
Aston	104
Astra	057,061,062,063,087,115,130,138,186,190
Astro	054,055,060,067,119,144,148,180,181,182,183,186
AudioTon	054,075,144
Aurora	193
Austar	017,193
Avalon	133
Axiel	189
Axis	060,063,071,132,138,182

Receiver Brand	Setup Code
Barcom	059
Best	059,060,182
Blaupunkt	067,119,180
Blue Sky	190,195
Boca	057,087,142,150,177,190
Boston	177,189
Brain Wave	069,128,153
Brandt	099
Broadcast	068,130
Broco	138,190
BSkyB	010,162
BSkyB	203
BT	189
BT Satellite	099,154
Bubu Sat	190
Bush	052,056,070,081,095,112,121,131
BVV	153
Cambridge	150,183
Canal Satellite	163,181
Canal+	097,181
Channel Master	053,131
Chaparral	090
CHEROKEE	189,199
Chess	103,179,185,190
CityCom	052,072,017,159,176,186,191
Clatronic	069,128
Clemens Kamphus	083
CNT	055
Colombia	177
Columbia	177
COLUMBUS	078
Comag	177
Commander	123
Commlink	054,126

Receiver Brand	Setup Code
Comtec	126,132
Comtech	071
Condor	060,182,186
Connexions	066,133,182
Conrad	141,142,176,177,182,183,186
Conrad Electronic	186,190
Contec	071,072,132,142
Cosat	075
Crown	057
Cybermaxx	108
D-Box	166
Daeryung	066
Daewoo	002,190
Dansat	056,112,121
DDC	053,131
Decca	073
Delega	053
Dew	071,132
Diamond	074
Digiality	186
Digipro	196
DirecTV	279,269,270,281,283,273,274,275,276,284
Discoverer	179,185
Discovery	189
Diseqc	189
Dish Network System	286,285,282,280
Diskxpress	059
Distratel	195
Distrisat	122
Ditristrad	075
DNR	153
DNT	066,093,122,133
Dong Woo	086
Drake	076

Receiver Brand	Setup Code
DStv	193
Dune	182
Dynasat	188
Echostar	066,103,133,163,165,190,199,286,285,282,280
Einhell	051,054,057,125,126,177,183,190
Elap	189,190
Elekta	055
Elsat	151,190
Elta	051,060,075,093,122,182
Emanon	051
Emme Esse	060,070,083,165,182,188
Engel	190
Ep Sat	052
EURIEULT	178,194,195
Eurocrypt	115
Eurodec	106
Europa	122,123,142,183,186
Europhon	177,186
Eurosat	057
Eurosky	057,060,176,177,182,183,186
Eurospace	077
Eurostar	057,167,176,186,188,191
Eutelsat	190
Eutra	147
Exator	051,054,144
Fenner	179,182,185,190
Ferguson	052,056,070,106,049,112,121,145
Fidelity	125,149,183
Finlandia	052,115
Finlux	052,061,080,115,136,141
Finnsat	071,106
Flair Mate	190
Foxtel	017,193,198
Fracarro	095,165

Receiver Brand	Setup Code
France Satellite/TV	078
Freecom	051,082,180,183
Freesat	147,194
FTE	058,084,142,150
FTEmaximal	182,190
Fuba	051,059,060,062,066,067,078,080,093,115,133,176,180,182
Fugionkyo	196
G-Sat	121
Galaxi	059
Galaxis	054,060,063,071,075,081,101,017,126,132,138,164,176,182,193
Galaxisat	127
Gardiner	191
GE	270
GMI	057
Goldbox	163,181
GoldStar	082
Gooding	184
Goodmans	052,081
Granada	061,115
Grandin	113,178
Grothusen	051,082
Grundig	052,054,067,070,094,105,010,029,031,032,034,043,118,119,129,156,158,162,180,183,184,193,195
Hanseatic	089,143,185
Hänsel & Gretel	177,186
Hantor	051,069,086,128
Hanuri	055
Hase & Igel	153
Hauppauge	025,044
Heliocom	058,186
Helium	186
Hinari	053,121,131
Hirschmann	067,083,030,119,133,134,135,137,141,180,182,183,186,189,194
Hisawa	069,128
Hitachi	052,070

Receiver Brand	Setup Code
HNE	177
Houstion	123
Houston	075
Hughes Network Systems	273,275,276,283,284
Humax	100,005,009,017,024,026,050
Humax	050
Humax	200
Humax	005
Huth	054,057,068,069,071,075,083,123,126,128,130,132,142,177,186,197
Hypson	178
ID Digital	017
Imex	178
Imperial	081,095
Ingelen	194
Innovation	060,089,101,103,108
International	177
Interstar	196
Intertronic	057
Intervision	075,146,186
ITT Nokia	052,061,070
ITT/Nokia	115,134,141,166
Johansson	069,128
JOK	152,154,189
JSR	075
JVC	184
K-SAT	190
Kamm	190
Kathrein	067,072,084,090,093,003,008,012,021,022,023,026,119,122,137,144,148,159,169,176,180,189,190,191,199
Kathrein	201
Kathrein Eurostar	176
Key West	177
Klap	189
Konig	186
Kosmos	082,083,084,137

Receiver Brand	Setup Code
KR	054,144,147
Kreismeyer	067,119,180
Kyostar	051,144,177
L&S Electronic	177,182
Lasat	055,060,085,086,087,132,150,176,177,179,182,186
Lemon	153
Lenco	051,082,088,123,138,153,176,182,186,190
Leng	069
Lennox	075
Lenson	079,183
Lexus	122
LG	082
Life	101
Lifesat	060,089,101,103,108,143,177,179,182,185,190
Lifetec	060,089,101,103,108
Lion	077
Lorenzen	123,153,155,177,186
Lorraine	082
Lupus	060,182
Luxor	061,115,129,141,166,183
Lyonnaise	106
M & B	143
M&B1	185
Macab	106
Manata	154,177,178,189,190
Manhattan	052,055,070,075,154,189
Marantz	093
Mascom	055,137
Maspro	052,070,090,114,119,147,153,156,180,184,190
Matsui	099,119,131,154,180,184,189
Max	186
MB	089,143,185
Mediabox	163,181
Mediamarkt	057

Receiver Brand	Setup Code
Mediasat	063,138,163,181,183
Medion	060,089,101,103,108,177,182,190
Medison	190
Mega	093,122
Meletronic	191
Metronic	051,054,055,059,113,126,144,159,178,190,191,195
Metz	067,119,180
Micro	183,186,190
Micro electronic	190
Micro Technology	077,138,190
Micromaxx	060,089,101,103,108,182
Microstar	060,089,101,103,108
Microtec	190
Minerva	067,184
Mitsubishi	052,067,099
Mitsumi	087
Morgan Sydney	107
Morgan's	057,087,093,122,142,150,177,190
Motorola	192,278,277
Multichoice	105,193
Multistar	084,086
Multitec	103,179
Muratto	065,082,127
Mysat	190
Navex	069,128
NEC	091,120
Network	121
Neuhaus	063,075,079,123,138,142,153,183,186,190
Neusat	153,190
Next Wave	102
NextWave	197
Nikko	057,190
Nokia	052,061,070,015,019,033,115,134,141,166,170,175
Nomex	109

Receiver Brand	Setup Code
Nordmende	051,052,053,055,106,128,131,145
Nova	193
Novis	069,128
Oceanic	074,077
Octagon	051,054,071,123,132,144
Okano	057,083,084
Ondigital	116,117,124
Optex	072,075
Optus	181,193,197
Orbit	064
Orbitech	051,139,140,142,179,181,183
Origo	077
Osat	054,129
Otto Versand	067
Pace	052,056,067,070,081,094,010,040,047,112,121,124,157,162,189,199
Pace	204
Pacific	074
Packsat	189
Palcom	053,062,078,079,131
Palladium	057,183,184
Palsat	179,183
Paltec	062
Panasat	187,193
Panasonic	001
Panasonic	052,070,094,001,010,162,274,272
Panda	052,056,112,115,180,186
Patriot	177,189
Philips	052,070,093,039,041,116,117,119,121,122,123,142,144,154,156,158,159,163,169,180,181,184,189,191,273,275,276,279,283
Phoenix	071,081,121,132
Phonotrend	052,054,075,083,126,164
Pioneer	163,181
Polsat	106
Polytron	072
Predki	069,128

Receiver Brand	Setup Code
Preisner	133,142,150,177
Premier	181
Premiere	075,097,017,163,181
Priesner	057
Profi	088
Profile	189
Promax	052
Prosat	053,054,081,095,126,131,146
Proscan	269,270
Prosonic	155
Protek	074
Provision	055
Pye	184
Quadral	053,054,060,126,131,142,146,154,182,189,199
Quelle	067,125,176,186
Quiero	106
Radiola	093,122
Radix	066,011,018,037,133,147,168,171,174,194
Rainbow	054,144,147
RCA	269,270,271,268,281
Red Star	182
Rediffusion	091
Redpoint	063,138
Redstar	060
RFT	054,093,122,123,126,139
Roadstar	190
Roch	178
Rover	146,182,190
Ruefach	088
Saba	055,070,077,095,121,145,152,153,154,176,186,189,195
Sabre	052
Sagem	106,160
Sakura	071,081,132
Salora	061,091,115

Receiver Brand	Setup Code
Samsung	051,006,007,016,028
SAT	053,064,065,127,149,183
Sat Cruiser	197
Sat Partner	183
Sat Team	190
Satcom	068,089,130,143,185,186
Satec	070,121,190
Satelco	182
Satford	068,130
Satline	146
Satmaster	068,130
SatPartner	051,054,055,069,082,083,128
Satplus	179
Schacke	144
Schneider	060,101,103,108,158,179,189
Schwaiger	072,074,089,100,102,121,142,143,177,179,185,186,195
SCS	176
Sedea Electronique	177,196
Seemann	057,063,066,138
SEG	051,060,069,089,128,143,155,182,185
Seleco	075,165
Septimo	195
Servi Sat	178,190
Siemens	067,119,150,180
Silva	082
Skantin	190
Skardin	063,138
Skinsat	183
SKR	190
SKY	192,288,289,290,291,292,293,294
Sky Digital	094
Skymaster	054,089,103,004,020,126,143,146,167,179,185,190
Skymax	093,122
SkySat	179,183,185,186,190

Receiver Brand	Setup Code
Skyvision	075
SL	153,177
SM Electronic	179,190
Smart	176,177,190,194
Sony	094,181
SR	057,087,177
Starland	103,190
Starring	069,128
Start Trak	051
Strong	051,054,060,082,095,182,193,196
STVI	178
Sumida	057
Sunny Sound	182
Sunsat	138,190
Sunstar	057,087,177,182
Super Sat	188
Supermax	197
Systec	177
Tandberg	106
Tandy	054
Tantec	052,070,078,079
Tatung	073
TCM	060,089,101,103,108,205,206,207,208,209,210,211,212,213,214,215,216,217,218,219,220
Techniland	068,130
TechniSat	066,079,000,013,014,027,111,122,139,140,172,173,179,181,183
Technology	193
Technosat	197
Technowelt	177,186,195
Teco	057,087
Telanor	053
Telasat	089,143,176,185,186
Teleciel	144
Telecom	190
Teledirekt	121

Receiver Brand	Setup Code
Telefunken	051,070,099,154,189
Teleka	054,057,066,133,137,144,153,156,183,186
Telemaster	055
Telemax	085
Telesat	089,143,185,186
Telestar	079,179,181,183
Teletech	167
Televes	052,107,177,183
Telewire	075
Tempo	197
Tevion	060,089,101,103,108,190
Thomson	052,096,099,106,035,038,042,045,046,048,145,176,181,186,189,190
Thorens	074
Thorn	052,056,070
Tioko	072,177
Tokai	122
Tonna	052,068,075,130,183,190
TPS	098
Triad	064,065,082,127
Triasat	080,136,183
Triax	067,079,136,176,177,183,190
Turnsat	190
Tvonics	049
Twinner	107,177,178,190
UEC	193,198
Uher	179
Uniden	092,149
Unisat	057,071,122,132,177
Unitor	059,069
Universum	067,119,134,149,155,176,180,184,186
V-Tech	064,127,152,159
Variosat	119,180
Variostat	067
Vector	077

Receiver Brand	Setup Code
Vega	182
Ventana	093,122
Vestel	155
Via Digital	096
Viasat	199
Visionic	196
Visiosat	069,075,103,104,152,189,190
Viva	123
Vivanco	110
Vivid	198
Vortec	051,124
VTech	065,191
Wela	142
Welltech	179
WeTeKom	179,183,185
Wevasat	052
Wewa	052
Winersat	069,128
Wintergarten	126
Wisi	052,064,065,066,067,119,127,133,142,152,180,183,186
Woorisat	055
World	128
Worldsat	189
Xrypton	182
XSat	190,199
Zaunkonig	153
Zehnder	055,059,060,065,084,036,127,155,159,176,182,191
Zehnder	202
Zenith	192
Zinwell	017
Zodiac	054,144

DVD Brand	Setup Code
-----------	------------

Aiwa	049,175
Akai	139
Akura	153
Alba	015,023,050
Apex Digital	208,209,210,211,212
Best Buy	152
Brandt	013,040,146
Bush	025,050,051,122,124,130,147,151
C-Tech	150
Cambridge Audio	149
Centrex	154
CGV	149
Classic	144
Clatronic	151
Conia	147
CyberHome	003,029,032,046
Daewoo	030,109,115,127
Dansai	070
Daytek	005,026
DEC	151
Denon	061,063,068
Denver	151,153
Denzel	148
Diamond	149,150
DK Digital	042,159
Dual	148
DVX	150
Easy Home	152
Eclipse	149
Elta	045
Eltax	157
Enzer	148
Finlux	149
GE	213,214,209

DVD Brand	Setup Code
Gericom	054
Global Solutions	150
Global Sphere	150
GoldStar	017
Goodmans	056,151,154
Graetz	148
Grundig	048,143,154
H&B	151
Haaz	149,150
HiMAX	152
Hitachi	012,058,145,148,152,168,181
Humax	059
Humax	059
Innovation	140,145
Insignia	230,232,217,218,219
JVC	020,052,118,119,146,160,220,221,222,223
JVC	085,086,087,088
Kenwood	047,067,171
Kingavon	151
Kiss	148
Koda	151
KXD	152
Lawson	150
Lenco	151
LG	017,024,031,126,169,224,225,226
LG	095
Life	140
Lifetec	140,145
Limit	150
Loewe	055
LogicLab	150
Luxor	154
Magnavox	146,151,155,227,228,229,230
Magnum	145

DVD Brand	Setup Code
-----------	------------

Marantz	060,064,065,142
Matsui	040,071
Medion	140,145
Memorex	233,234,235,236
Metz	138
MiCO	149
Micromaxx	140,145
Micromedia	146
Microstar	140,145
Mizuda	151,152
Monyka	148
Mustek	001,144,163
Mx Onda	149
Naiko	154
Neufunk	148
NU-TEC	147
Onkyo	141,146,155
Orava	151
Orion	069,122
Oritron	140
P&B	151
Pacific	150
Panasonic	014,016,039,111,117,131,162,166,167,176,237,227,238
Panasonic	081,090,092
Panasonic	081,090
Philips	000,006,027,034,037,043,060,108,125,142,146,155,158,227,228,239,229,230,241,242,243,244
Philips	079,080,089,091,093,094
Philips	101,105
Pioneer	007,008,011,035,057,138,172,248,255,250,251,238
Pioneer	102,103,104
Proline	154
Proscan	213
Provision	151
Raite	148

DVD Brand	Setup Code
-----------	------------

RCA	213,255,209,256,257,258,259,260,261
RedStar	153
Reoc	150
Roadstar	066,151
Rowa	147,154
Saba	013,040
Sabaki	150
Samsung	012,019,112,114,116,165,237,262,263,264
Samsung	075,099,107
Samsung	106
Sansui	149,150
Sanyo	036,044,123,161,170,265,233,266
ScanMagic	001
Schneider	140
Scientific Labs	150
Scott	021
SEG	015,033,148,150
Sharp	038,113,120,267,230,268
Sigmathek	152
Silva	153
Singer	149,150
Skymaster	033,144,150
Skyworth	153
SM Electronic	150
Sony	004,009,010,018,022,028,041,110,156,164,173,174,216,240,249,215
Sony	072,073,074,076,077,078,082,083,084
Soundmaster	150
Soundmax	150
Standard	150
Star Cluster	150
Starmedia	151
Supervision	150
Sylvania	230,231,232,246
Synn	150

DVD Brand	Setup Code
-----------	------------

TCM	132,133,134,135,136,137,140,145,177,178,179,180
TCM	133
Teac	062,138,147,150
Tec	153
Tevion	140,145,150
Thomson	013,128
Tokai	148,153
Toshiba	002,121,129,146,155,227,233,247,252,253,254
Toshiba	096,097,098
Toshiba	096
TruVision	152
Wharfedale	149,150
Xlogic	150
Yakumo	154
Yamada	154
Yamaha	053
Yamakawa	148
Yukai	001
Yukai	100
Zenith	146,155

TV Brand	Setup Code
A.R. Systems	223
Acme	211
Acura	212,219
ADC	210
Admiral	209,210,214,215
Adyson	211,225,226,232,233
Agashi	232,233
Agazi	210
AGB	238
Aiko	211,212,219,223,225,226,232,233
Aim	223
Aiwa	193
Akai	212,213,216,218,219,223,226,227,231,232,233,238
Akiba	213,223,227,228
Akura	210,213,219,223,227,228
Alaron	232
Alba	211,212,213,218,219,222,223,225,227,232,237
Alcyon	224
Allorgan	226,233
Allstar	216,223
Amplivision	211,226,230,233,237
Amstrad	210,212,213,219,223,227,238
Anam	212
Anglo	212,219
Anitech	210,212,219,223,224
Ansonic	212,219,221,223,236,237
AOC	300,301
Apex Digital	303
Arc en Ciel	229
Arcam	225,226,232,233
Arcam Delta	211

TV Brand	Setup Code
Aristona	216,218,221,223,231
Arthur Martin	230
ASA	209,215
Asberg	216,223,224
Astra	212
Asuka	210,211,213,225,226,227,228,232,233
Atlantic	211,216,218,223,225,232
Atori	212,219
Auchan	230
Audiosonic	211,212,213,216,218,223,226,227,233,237
AudioTon	211,226,233,237
Ausind	224
Autovox	209,210,211,224,226,233
Awa	232,233
Baird	226,233
Bang & Olufsen	209
Basic Line	212,213,216,219,223,227,228,233
Bastide	211,226,233
Baur	218,220,223
Bazin	226,233
Beko	065,077,223,237
Beon	216,218,223
Best	237
Bestar	216,223,237
Binatone	211,226,233
Blacktron	228
Blackway	228
Blue Sky	213,223,227,228
Blue Star	228
Boots	211,226,233
BPL	223,228

TV Brand	Setup Code
Brandt	003,006,007,229
Brinkmann	223
Brionvega	209,216,218,223
Britannia	211,225,226,232,233
Bruns	209
BSR	217
BTC	213,227
Bush	101
Bush	034,180,184,193,212,213,214,216,217,218,219,222,223,226,227,228,233
Capsonic	210
Carena	223
Carrefour	222
Cascade	212,219,223
Cathay	216,218,223
CCE	233
Centurion	216,218,223
Century	209
CGE	217,224,237
Cimline	212,219,227
City	212,219
Clarivox	218
Clatronic	210,211,212,213,216,219,223,224,226,227,233,237
CMS	232
CMS Hightec	233
Concorde	212,219
Condor	211,216,219,223,225,228,232,237
Contec	211,212,219,222,225,232
Continental Edison	229
Cosmel	212,219
Crosley	209,217,224
Crown	212,216,218,219,223,224,237

TV Brand	Setup Code
CS Electronics	211,213,225,227,232
Cybertron	213,227
Daewoo	106
Daewoo	138
Daewoo	018,035,066,182,192,194,211,212,216,219,223,225,226,227,232,233,240
Dainichi	213,225,227,232
Dansai	210,216,218,223,225,232,233
Dantax	218,237
Dawa	223
Daytron	212,219
De Graaf	214
Decca	211,216,218,223,226,233,238
Denver	096
Desmet	216,218,223
Diamant	223
Diamond	232
Dixi	212,216,218,219,223,233
DTS	212,219
Dual	211,217,223,226,233
Dual-Tec	211,212,217,226
Dumont	209,211,226,233
Dux	218
Dynatron	216,218,223
Elbe	223,227,233,236,237,238
Elbe-Sharp	238
Elcit	209,238
ELECTRO TECH	212
Elektra	228
Elin	211,216,218,219,223,225,232
Elite	213,216,223,227
Elman	217

TV Brand	Setup Code
Elta	212,219,232
Emerson	209,223,237,277,311,312,296,314,316,317
Emperor	228
ESC	233
Etron	212
Euro-Feel	210
Eurofeel	233
Euroline	218
Euroman	228,232,233,237
Euromann	210,211,216,223,225,226
Europhon	211,216,217,223,226,232,233,238
Expert	230
Exquisit	223
Fenner	212,219
Ferguson	031,060,218
Fidelity	211,214,223,225,232
Filsai	233
Finlandia	214
Finlux	209,211,216,217,218,223,224,226,233,238
FIRST LINE	211,212,216
Firstline	219,223,225,226,232,233
Fisher	209,211,217,222,226,233,237
Flint	216,223,227
Formenti	209,211,217,218,224,225,232
Formenti-Phoenix	232
Fortress	209
Fraba	223,237
Friac	237
Frontech	210,212,214,215,219,233
Fujitsu	226,233
Fujitsu General	233

TV Brand	Setup Code
Funai	210
Galaxi	223
Galaxis	223,237
GBC	212,217,219,227
GE	327,328,329,312,316
Geant Casino	230
GEC	211,215,216,218,223,226,233,238
Geloso	212,214,217,219
General Technic	212,219
Genexxa	213,215,216,223,227
Giant	233
GoldHand	232
Goldline	223
GoldStar	211,212,214,216,217,218,219,223,225,226,232,233,234,237
Goodmans	123
Goodmans	203,210,212,216,218,219,222,223,226,231,233,234,238,240
Gorenje	237
GPM	213,227
Graetz	215
Granada	211,214,216,218,221,222,223,224,226,230,233,238
Grandin	212,213,218,228
Gronic	233
Grundig	010,075,200,223,224,231,237
Halifax	210,211,225,226,232,233
Hampton	211,225,226,232,233
Hanseatic	211,212,216,217,218,219,223,226,228,233,236,237
Hantarex	212,219,223,238
Hantor	223
Harwood	219,223
HCM	210,211,212,219,223,226,227,228,233
Hema	219,226,233

TV Brand	Setup Code
Higashi	232
HiLine	223
Hinari	212,213,216,218,219,222,223,227
Hisawa	213,227,228,230
Hitachi	089
Hitachi	139,144
Hitachi	154
Hitachi	171
Hitachi	058,061,211,214,215,217,222,223,226,233,238,240,341,342,343
Hornyphon	216
Hornyphone	223
Hoshai	213,227
Huanyu	211,225,232
Hygashi	211,225,226,232,233
Hyper	211,212,217,219,225,226,232,233
Hypson	210,211,216,218,223,226,228,230,233
Iberia	223
ICE	210,211,212,213,216,219,223,225,226,227,232,233
ICeS	225,227,232
Imperial	215,216,217,223,224,237
Indiana	216,218,223
Ingelen	215
Ingersol	212,219
Inno Hit	211,212,213,216,218,219,223,224,226,227,233,234,238
Innovation	210,212
Insignia	348,349,317,351,352,353,354,355,356,357,296
Interactive	237
Interbuy	212,219
Interfunk	209,215,216,218,221,223,237
International	232
Intervision	210,211,223,226,227,228,233,237

TV Brand	Setup Code
Irradio	212,213,216,218,219,223,224,227,234
Isukai	213,223,227,228
ITC	211,217,226,233
ITS	213,216,223,225,227,228,232
ITT	212,215
ITV	212,218,223
JVC	132
JVC	155
JVC	216,222,227,362,363,364,365
Kaisui	211,212,213,219,223,225,226,227,228,232,233
Kamosonic	211
Kamp	211,225,232
Kapsch	215
Karcher	211,212,218,223,228,237
Kawasho	232
Kendo	214,223,237
Kennedy	217
KIC	233
Kingsley	211,225,232
Kneissel	223,236,237
Kolster	216,223
Konka	213,227
Korpel	216,218,223
Korting	209,237
Kosmos	223
Koyoda	212
KTV	211,233
Kyoto	232,233
Lasat	237
Lenco	212,219
Lenoir	211,212,219

TV Brand	Setup Code
Leyco	210,216,218,223
LG	081,084,094,095,098,105,110,111,114,118,126,136,168
LG	136
LG	140,148
LG	164,168
LG	195,211,212,214,216,217,218,219,223,225,226,232,233,234,237,348,277,271,316
Liesenk	218
Liesenkotter	223
Life	210,212
Lifetec	210,212,219,223,227
Lloyds	219
Loewe	014,055,223,236,237,238
Loewe Opta	209,216,218
Luma	214,218,219,223
Lumatron	214,216,218,223,226,233
Lux May	216
Luxor	211,214,233,234
M Electronic	211,212,215,216,218
M-Electronic	219,223,225,226,232,233
Magnadyne	209,217,218,238
Magnafon	211,224,225,232,238
Magnavox	272,273,274,275,329,300,278,279,280,291,301,293,294,323
Magnum	210,212
Mandor	210
Manesth	210,211,216,218,223,226,233
Marantz	216,218,223
Marelli	209
Mark	216,218,219,223,225,226,232,233
Masuda	233
Matsui	133
Matsui	211,212,214,216,218,219,222,223,226,231,233,238

TV Brand	Setup Code
Medion	210,212,223
Melvox	230
Memorex	212,219
Memphis	212,219
Mercury	219,223
Metz	209
Micromaxx	210,212
Microstar	210,212
Minerva	224,238
Minoka	216,223
Mitsubishi	170
Mitsubishi	209,216,222,223,297,298,299,316,334
Mivar	211,224,225,232,233,234,235,236,237,238,239
Motion	224
MTC	232,237
Multi System	218
Multitech	211,212,214,217,218,219,223,225,226,232,233,237
Murphy	211,225,232
Naonis	214
NEC	222,233
Neckermann	209,211,214,216,218,220,223,226,231,233,237
NEI	216,218,223
Neufunk	219,223,231
New Tech	212,216,219,223,226,231
New World	213,227
NewTech	233
Nicamagic	211,225,232
Nikkai	210,211,213,216,218,219,222,223,225,226,227,232,233
Noblisko	211,224,225,232
Nokia	215
Nordic	233

TV Brand	Setup Code
Nordmende	209,215,216
Nordvision	218
Novatronic	223
Oceanic	215,230
Okano	223,237
ONCEAS	211
Onwa	227
Opera	223
Orbit	216,223
Orion	062,203,212,216,218,219,223,238
Online	223,227
Orsowe	238
Osaki	210,211,213,223,226,227,233
Osio	234
Oso	213,227
Osume	222,227
Otto Versand	211,216,217,218,220,222,223,226,231,233,238
Pael	211,225,232
Palladium	211,220,223,226,231,233,237
Palsonic	233
Panama	210,211,212,219,223,225,226,232,233
Panasonic	161
Panasonic	091,102,112
Panasonic	137,147
Panasonic	004,013,020,024,026,044,050,057,073,185,198,215,223,238,306,307,308,329,300,363
Panavision	223
Pathe Cinema	211,217,225,230,232,236,237
Pathe Marconi	229
Pausa	212,219
Perdio	223,232
Perfekt	223

TV Brand	Setup Code
Philco	209,217,223,224,237
Philharmonic	211,226,233
Philips	173,176,178
Philips	167
Philips	078,079
Philips	078
Philips	134,152
Philips	142
Philips	143,156
Philips	002,005,009,012,016,019,021,022,023,029,033,036,037,038,041,042,045,052,059,069,076,181,186,187,188,189,190,191,196,197,209,211,216,217,218,221,223,231,272,275,283,284,291,286,287,288
Philips	079
Phoenix	209,216,218,223,225,232,237
Pioneer	141,146,149,151
Pioneer	163
Pioneer	215,216,218,223,237
Plantron	210,216,219,223
Playsonic	226,233
Polaroid	359,352,290
Poppy	212,219
Prandoni-Prince	214,224,238
Precision	211,226,233
Prima	212,215,219
Profex	212,219
Profi-Tronic	216,223
Proline	216,221,223
proscan	327,328,333,335,315,318
Prosonic	211,218,223,225,232,233,237
Protech	210,211,212,216,217,218,233
Provision	218,223,240
Pye	216,218,221,223,231

TV Brand	Setup Code
Pymi	212,219
Quandra Vision	230
Quelle	210,211,216,217,218,220,222,223,226,233,234
Questa	222
R-Line	216,218,223
Radialva	223,227
Radiomarelli	209,223,238
RadioShack	223
Radiotone	216,219,223,237
RCA	325,327,328,329,298,337,338,359,339,340,344,335,334,346,333
Recor	223
Redstar	223
Reflex	223
Revox	216,218,223,237
Rex	210,214,215
RFT	209,236,237
Rhapsody	232
Roadstar	193,210,212,213,219,227
Robotron	209
Rowa	232,233
Royal Lux	237
RTF	209
Saba	006,060,068,172,209,215,238
Saisho	210,211,212,219,226,233,238
Salora	214,215,217,234,238
Sambers	224,238
Samsung	177
Samsung	080,082,083,087,093,097,104,113,116,121
Samsung	150
Samsung	135
Samsung	166

TV Brand	Setup Code
Samsung	039,043,056,063,070,201,210,211,212,216,218,219,223,225,226,231,232,233,234,237,358,275,305,310,316,300,345,363
Sandra	211,225,226,232,233
Sansui	216,223,314,317,322,326
Sanyo	160
Sanyo	049,211,217,219,222,225,226,232,233,236,237,275,311,330,331,350,270
SCHAUB LORENTZ	215
Schneider	211,213,216,217,218,221,223,226,227,231,233
SEG	210,211,217,218,219,222,223,225,226,232,233
SEI	220,223,238
SEI-Sinudyne	209,215,238
Seleco	214,215,217
Sencora	212,219
Sentra	219,227
Serino	232
Sharp	162
Sharp	131
Sharp	092,103,109,115,119,120,122,127,128
Sharp	017,028,048,051,072,222,238,276,298,292,295,302,334
Siarem	209,217,223,238
Sierra	216,221,223,231
Siesta	237
Silva	225,232
Silver	222
Singer	209,217,230
Sinudyne	209,217,218,220,223,238
Skantic	215
Solavox	215
Sonitron	226,233,237
Sonoko	210,211,212,216,218,219,223,226,228,233
Sonolor	215,220,230
Sontec	216,218,223,237

TV Brand	Setup Code
Sony	174,175,179
Sony	158,159
Sony	108
Sony	085,086,088,107,117
Sony	000,001,008,011,015,025,030,040,054,071,199,202,212,220,222,304,309,313,281,332
Sound & Vision	213,227
Soundwave	216,218,223
Standard	211,212,213,216,219,223,226,227,233
Star Lite	219,223
Starlight	218
Stenway	227,228
Stern	214,215
Strato	219,223
Stylandia	233
Sunkai	212,227
Sunstar	219,223
Sunwood	212,216,219,223
Superla	211,225,232,233,238
SuperTech	219,223,225,231,232
Supra	212,219
Susumu	213
Sutron	212,219
Sydney	211,225,226,232,233
Sylvania	367,275,300,317,278,282,290,319,320,285,294,323,296
Sysline	218
Sytong	225,232
Tandy	211,213,215,226,227,233
Tashiko	211,214,222,225,226,232,233
Tatung	193,211,216,218,223,226,233,238
TCM	204,205,206,207,208,210,212,241,242,243,244,245,246,247,248,249,250,251,252,253,254,255,256,257,258,259,260,261,262,263,264,265,266,267,268
Teac	223,233

TV Brand	Setup Code
Tec	211,212,217,219,226,233
TEDELEX	233
Teleavia	229
Telecor	223,226,227,233
Telefunken	165
Telefunken	216,223
Telegazi	223,227
Telemeister	223
Telesonic	223
Telestar	223
Teletech	212,218,219,223
Teleton	211,222,226,233
Televideon	225,232
Televiso	230
Tensai	212,213,216,219,223,226,227,233
Tesmet	216
Tevion	210,212
Texet	211,219,226,232,233
Thomson	145,157
Thomson	003,006,032,060,067,172,211,216,223,229
Thorn	218,223,240
Tokai	216,223,226,233
Tokyo	211,225,232
Tomashi	228
Toshiba	169
Toshiba	130
Toshiba	099,100,124
Toshiba	153
Toshiba	027,046,047,053,064,074,090,183,193,203,222,233,326,311,303,289,271,347,324,363
Towada	215,217,233
Trakton	233

TV Brand	Setup Code
Trans Continens	223,226,233
Transtec	232
Trident	226,233,238
Tristar	227
Triumph	223,231,238
Uher	215,216,223,224,237
Ultravox	209,211,217,223,225,232
Unic Line	223
United	218
Universum	210,216,217,218,220,222,223,224,226,233,234,237
Univox	223
Vestel	214,215,216,217,218,223,226,233
Vexa	212,218,219,223
Victor	216
VIDEOLOGIC	232
Videologique	211,213,225,226,227,232,233
VideoSystem	216,223
Videotechnic	225,226,232,233
Viewsonic	125,129
Viore	275
Visiola	211,225,232
Vision	216,223,233
Vizio	360,361,366,336
Vortec	216,218,223
Voxson	209,214,215,216,223,224
Waltham	211,223,226,233
Watson	216,218,223,227
Watt Radio	211,217,225,232
Wega	209,222,223
Wegavox	219
Weltblick	216,218,223,233

TV Brand	Setup Code
Westinghouse	304,312,366
Weston	217
White Westinghouse	211,218,223,225,232
Windstar	228
Xrypton	223
Yamishi	223,226,227,228,233
Yokan	223
Yoko	210,211,212,213,216,218,219,223,226,227,232,233,237
Yorx	213,227
Zanussi	214,226,233

CBL Brand	Setup Code
-----------	------------

ABC	246
Alcatel	244,245
Amino	251,252
Amstrad	221,249
Arcon	221
Axis	221
Cabletime	222,223,240,242
Cisco	253,254,255
Clyde Cablevision	224
Comcrypt	247
Cryptovision	225
Fidelity	221
Filmnet	247
Filmnet Cablecrypt	226,241
Filmnet Comcrypt	226
Finlux	228
Foxtel	249
France Telecom	243,248
Freebox	250
GEC	224
General Instrument	239,246
Gooding	227
Grundig	221,227
Hirschmann	228
ITT Nokia	228
Jerrold	229,235,237,239,246
JVC	227
M-Net	241
Macab	248
Maspro	227
Matsui	227
Minerva	227
Mnet	247
Motorola	256,257,258,259,260,261

CBL Brand	Setup Code
-----------	------------

Movie Time	234
Mr Zapp	248
Multichoice	247
Nokia	228
Noos	248
Palladium	227
Panasonic	262,263,255
Philips	227,236,243,248,264
Pioneer	221,230,231
PVP Stereo Visual Matrix	237
RCA	266
Sagem	248
SAT	221
Scientific Atlanta	232,233,253,254,267
Starcom	246
Tele +1	226
Tele+1	241,247
Telepiu	241,247
Torx	246
United Cable	237
Universum	227,228
Videoway	238
Visiopass	228,243,248
Wittenberg	221